REMOVAL AND INSTALLATION: HEA...

REMOVAL AND INSTALLATION: HEADLINER (INTERIOR TRIM AND ORNAMENTATION) Procedure SGML ID: N161286

SECTION 501-05: Interior Trim and Ornamentation   2002 Explorer Sport/Sport Trac Workshop Manual

REMOVAL AND INSTALLATION   Procedure revision date: 02/22/2002

Headliner

Removal and Installation

All Vehicles

1. Disconnect the battery ground cable. For additional information, refer to Section 414-01.

Sport Trac

2. Remove the C-pillar trim panel. For additional information, refer to C-Pillar Trim Panel in this section.

Explorer Sport

3. Remove the rear quarter trim panel. For additional information, refer to Rear Quarter Trim Panel in this section.

All Vehicles

4. Remove the overhead console. For additional information, refer to Section 501-12.

5. Remove the interior lamp lens.

GK0523-A

6. Remove the screws and the interior lamp.

GK0524-A

7. Remove the two sun visors.
   1. Remove the six screws.
   2. Remove the two sun visors.
   - If equipped, disconnect the electrical connectors.

GR2506-A

8. Remove the two sun visor brackets.
   1. Remove the two screws.
   2. Remove the two sun visor brackets.

GR2507-A

9. Remove the six assist handle bolt covers.

R12538-B

10. Remove the three assist handles.
    1. Remove the six bolts.
    2. Remove the three assist handles.

R12539-A

Sport Trac

11.

NOTE: The headliner is removed through the passenger side front door.

Remove the passenger seat. For additional information, refer to .

All Vehicles

12. Remove the headliner.

13. To install, reverse the removal procedure.

This publication contains material that is reproduced and distributed under a license from Ford Motor Company. No further reproduction or distribution of the Ford Motor Company material is allowed without the express written permission of Ford Motor Company.